

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5






FIG. 6

DSC



PD PRINTER

FIG. 7





FIG. 8

	TYPE OF COMMAND	BASIC	RECOMMENDED	EXTENDED	FUNCTION
PRINTER	NCDPStart	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	START NCDP
	ProcedureStart	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	START BASIC, RECOMMENDED, OR EXTENDED MODE
	NCDPEnd	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	TERMINATE FROM NCDP
	Capability		<input type="radio"/>		NOTIFY PRINTER FUNCTION
	GetImage	<input type="radio"/>	<input type="radio"/>		ACQUIRE DIGITAL IMAGE
	StatusSend		<input type="radio"/>		NOTIFY FATAL ERROR
	PageStart		<input type="radio"/>		NOTIFY PRINT START (UPON FEEDING SHEET FOR EACH PAGE)
	PageEnd		<input type="radio"/>		NOTIFY PRINT END (UPON DISCHARGING SHEET FOR EACH PAGE)
	JobEnd	<input type="radio"/>	<input type="radio"/>		NOTIFY END OF PRINT JOB
	JobDataDone	<input type="radio"/>	<input type="radio"/>		NOTIFY COMPLETION OF RECEPTION OF JOB DATA
	JobStart	<input type="radio"/>	<input type="radio"/>		PRINT START MESSAGE
DIGITAL CAMERA	JobAbort		<input type="radio"/>		PRINT ABORT MESSAGE
	JobContinue		<input type="radio"/>		PRINT RESTART MESSAGE

FIG. 9







FIG. 11

12/17

FIG. 12

PRINT IN PROGRESS . . .

DO NOT REMOVE CABLE

FIG. 13

PRINT IN PROGRESS . . .

CABLE CAN BE REMOVED.
(PHOTOGRAPHING CAN BE MADE)

14/17

FIG. 14




FIG. 15




FIG. 16

PRINT IN PROGRESS . . .

DO NOT BRING CAMERA
OUTSIDE COMMUNICATION AREA

FIG. 17

PRINT IN PROGRESS . . .

CAMERA CAN BE BROUGHT
OUTSIDE COMMUNICATION AREA
(PHOTOGRAPHING CAN BE MADE)